


#### **BBOXX Home**

# Accessing the Electronics





#### Introduction

This guide will show you how to safely and correctly access and isolate the BBOXX Home electronics.

# Requirements

You do not need any tools or items to complete this guide

# Prerequisites

This guide follows on from the following:

- UG-000002: BBOXX Home- Case Disassembly
- UG-000004: BBOXX Home- Disconnect the Battery


#### Instructions

Follow the instructions below to learn how to safely remove the SMART control board and power management board from a BBOXX Home.

13 Jun 2016 **2** of 9



# Step 1 – Open the case




• Follow the steps in **UG-000002: BBOXX Home- Case Disassembly** to correctly open the BBOXX Home.

13 Jun 2016 3 of 9



#### Step 2 – Disconnect the battery



• Follow the steps in **UG-000004: BBOXX Home- Disconnect the Battery** to correctly and safely disconnect power from the BBOXX Home electronics.


#### **WARNING**

It is very importantly you correctly disconnect the battery from the electronics before proceeding. If you do not follow the steps outlined in UG-000004 you risk damaging the BBOXX Home electronics.

13 Jun 2016 **4** of 9



### Step 3 – Disconnect the antennae



• Carefully lift the tape securing the antennae connectors in place and unclip the antennae connectors from the SMART control board.

13 Jun 2016 **5** of 9




# Step 4 – Disconnect the temperature sensor cable

• Gently wiggle and pull out the temperature sensor connector from the SMART control board.

13 Jun 2016 **6** of 9



# Step 5 – Remove the PCB pair




• Pull the PCB pair straight up to remove them from the case.

**13** Jun 2016 **7** of 9



# Step 6 – Separate the PCBs



• Firmly grip both boards and gently pull apart to separate the PCBs.

You have successfully accessed the SMART control board and the power management board.

13 Jun 2016 **8** of 9



## **Additional Support**

If any of the below are true please contact BBOXX Product Support directly for help.

- I did not find this document helpful
- One or more of the steps in this document are confusing to follow
- There are errors in this document

Contact us at

products@bboxx.co.uk

13 Jun 2016 **9** of 9