


#### **BBOXX Home**

# Replacing or Reconnecting the SMART Control Board





### Introduction

This guide will show you how to correctly replace a SMART control board to ensure minimal risk in damaging the electronics.

# Requirements

You do not need any tools or items to complete this guide

# **Prerequisites**

If you have not already accessed the electronics then you will first need to follow the steps outlined in:

• UG-000002: BBOXX Home- Accessing the Electronics


## **Instructions**

Follow the instructions below to learn how to safely remove the SMART control board and power management board.

13 Jun 2016 **2** of 9



# Step 1 – Access the electronics




• Follow the steps in **UG-000009: BBOXX Home- Accessing the Electronics** to safely access and remove the power management board and the SMART control board.

13 Jun 2016 **3** of 9



# Step 2 – Visual check the SMART control board




- Complete a visual check on the SMART control board you are connecting to the BBOXX Home.
- Pay particular attention to areas/components highlighted in the image above.
- Look out for obvious physical damage such as chips or burn marks.

13 Jun 2016 **4** of 9



#### Step 3 – Connect the PCB pair



- Bring the power management board and SMART control board together and very carefully align their connectors. Look at the connection from multiple angles to make sure the alignment is right.
- When happy, gently\* squeeze the boards together.

#### \*WARNING

If the boards resist being pushed together then check the pins are all correctly aligned and check for bent pins. Do not apply a lot for force as you risk damaging the connectors

13 Jun 2016 **5** of 9



# Step 4 – Inspect the PCB pair


- Visually check that the board alignment is correct:
  - o Confirm that the long edge of both boards line up next to each other.
  - o Make sure none of the board-to-board connector gold pins are visible.
- The following pages show good versus bad board alignment.

You have successfully replaced a SMART control board.

13 Jun 2016 **6** of 9




#### The long edge of both boards should align



13 Jun 2016 **7** of 9



#### Gold pins should not be visible when connected correctly



13 Jun 2016 **8** of 9



# **Additional Support**

If any of the below are true please contact BBOXX Product Support directly for help.

- I did not find this document helpful
- One or more of the steps in this document are confusing to follow
- There are errors in this document

Contact us at

products@bboxx.co.uk

13 Jun 2016 **9** of 9